

# IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

## READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

**DANGER**—Any appliance is electrically live even when the switch is off.

- To reduce the risk of death by electric shock:
1. **Always unplug appliance immediately after using.**
  2. Do not use while bathing or in the shower.
  3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
  4. Do not place in, or drop into water or other liquids.
  5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

**WARNING** — To reduce the risk of burns, electrocution, fire, or injury to persons:

1. **This appliance should never be left unattended when plugged in.**
2. This appliance should not be used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

4. **Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.**

5. Keep the cord away from heated surfaces. Do not pull, twist, or wrap cord around appliance, even during storage.
6. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and other debris.
7. Never use while sleeping.
8. Never drop or insert any object into any opening or hose.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Do not use an extension cord to operate appliance.
11. This curling iron is hot when in use. Do not let heated surfaces touch eyes or skin.
12. **Do not place the heated curling iron directly on any surface or on the appliance power cord while it is hot or plugged in.**
13. Do not touch hot surface of the appliance; use handles or cool tip.
14. Before plugging in, read the information about dual voltage in the Operating Instructions section of this manual.
15. Do not use a voltage converter with this product.
16. This appliance is not a toy. Keep away from children.

## SAVE THESE INSTRUCTIONS

# OPERATING INSTRUCTIONS

This curling appliance is intended for household use. Use on Alternating Current (50/60 hertz) only. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

**NOTE: Due to high heat temperatures, this styler should not be used on hair extensions.**

### DUAL VOLTAGE

This curling iron has dual voltage. It will automatically adjust to the proper voltage. Use an adapter plug with correct configuration prior to use in outlet.

### MULTILAYER TECHNOLOGY

The barrel of your curling iron has a multilayer coating of steel, nickel, copper, nickel and chromium that retains heat and provides even heat distribution. The chromium surface smoothes and protects hair.

### USING INSTANT HEAT, THE 25 VARIABLE TEMPERATURE SETTINGS AND HEAT RECOVERY SYSTEM

This styling iron features Conair's® Instant Heat technology. It quickly heats up to the temperature you've selected for your hair type.

The iron's 25 temperature settings and Instant Heat technology provide styling versatility for all hair types. If you have fine hair, a low temperature will provide the best results. If you have thick, wavy or hard-to-curl hair, keep the heat setting on high. You can vary the iron's temperature according to your particular need!

### Temperature Setting Guide

Temp. Control	Hair Type
Low 1–8	Fine/Thin Hair
Medium 9–14	Medium/Normal Hair
Med-High 15–20	Wavy/Curly Hair
High 21–25	Coarse/Thick Hair
Turbo Heat®	Up to 20°C/36°F burst of heat for difficult styling spots

Conair's professional salon standards of engineering provide you with a Uniform Heat Recovery System that maintains the curling iron at constant temperatures.


There is a constant surge of power to ensure that heat is continuously delivered for optimal styling results, unlike other units which lose heat during use. This recovery system provides consistent styling power so that every strand of your hair is set with the same level of heat and comes out the same way for a perfect finish.

### GETTING STARTED

Plug the curling iron cord into a standard household electrical outlet (120/240V). **Never leave your curling iron on and unattended.** However, should you fail to turn the unit off, it will shut itself off automatically within 60 minutes at 60 Hz, 72 minutes at 50 Hz.

**WARNING: The iron's barrel will get very hot within a few seconds and should not be placed in contact with skin after the curling iron is turned on.**

### GET TO KNOW YOUR CURLING IRON



### TO CURL HAIR

Hair should be clean and completely dry before using the curling iron. Section hair evenly, and comb each section before winding. For best results, use a light styling product before blow-drying hair.

1. Start curling with a hair section that is 1 inch wide and no more than ½ inch thick. Open the spoon and place curling iron midway up the hair section, then spread hair evenly between spoon and barrel. Gently slide the curling iron down to hair ends. To avoid crimped ends, make sure they are securely wound under the spoon in the direction of the desired curl. Remember, always place the spoon above the hair strand when making a curl you want rolled under; place the spoon under the hair strand when creating a flip style.

2. Wind the hair up as far as you want it curled, being careful not to let the iron touch the scalp. Hold 8–12 seconds, depending on the length and texture of your hair. For tighter, bouncier curls, roll less hair. For looser, free-flowing curls, roll more hair. Repeat process on additional sections of hair until you achieve the style you desire.

3. To remove the curling iron, unwind the hair and press the handle and allow curl to slide out. To set curl, do not comb or brush curls until cool.

4. To achieve faster styling results, these units feature a unique, optional Turbo Heat® burst. Press the Turbo button to deliver up to 20°C/36°F more heat for maximum styling performance.

AVAILABLE IN THE FOLLOWING SIZES:

½ in. (13mm)  
Model CD80

¾ in. (19mm)  
Model CD81

1 in. (25mm)  
Model CD87

1¼ in. (32mm)  
Model CD82

1½ in. (38mm)  
Model CD89

## USER MAINTENANCE

Your curling iron is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the curling iron from the power source, let it cool, and wipe exterior with a cloth. If any abnormal condition occurs, unplug the curling iron, allow it to cool, and return it for repair to an authorized service center only. No repairs should be attempted by the consumer.

### CAUTION

NEVER allow the power supply cord to be pulled or twisted. Never wrap the cord around the curling iron. Damage will occur at the high flex point of entry into the curling iron, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

### STORAGE

When not in use, your appliance should be disconnected, allowed to cool, and stored in a safe, dry location, out of reach of children. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

## FEDERAL COMMUNICATIONS COMMISSION NOTICE

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### SUPPLIER'S DECLARATION OF CONFORMITY

**Brand:** Conair®

**Model No.:** CD80N/CD80WCSR

CD81GB/CD81GN/CD81N/CD81WCSR/  
CD81WM3

CD82N/CD82W3N/CD82WCSR/CD82WM3

CD87GB/CD87GN/CD87N/CD87W3N/CD87WM3

CD89W3N/CD89WCSR/CD89WM3/CD89N

**Description:** Curling Iron

**Responsible Party:** Conair Corporation,  
1 Cummings Point Road, Stamford, CT 06902,  
(203) 351-9000

**Standards:** FCC Part 15 Subpart B, ANSI C63.4-2014


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesirable operation.

**DATE OF ISSUE: 05/06/2019**

**WARNING:  
IF YOU THINK  
THE POWER IS OFF  
WHEN THE SWITCH  
IS OFF,  
YOU'RE WRONG.**

**KEEP AWAY FROM WATER**



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG  
SMALL APPLIANCES**

## LIMITED TWO-YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed on back, together with your purchase receipt and \$7.50 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture.

**ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

**IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.** Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

### BEAUTY TIPS:

To achieve the looks you love and for more great Conair® products, visit [conair.com](http://conair.com)

### Service Center

Conair Corporation  
Service Department  
7475 N. Glen Harbor Blvd.  
Glendale, AZ 85307

Please register this product at [www.conair.com/registration](http://www.conair.com/registration)

For information on any Conair product, call 1-800-3-CONAIR or visit us on the web at [www.conair.com](http://www.conair.com)

©2020 Conair Corporation

18PA050009

IB-14040C

# INSTANT HEAT



### Instructions & Styling Guide

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

## CONAIR®

Models CD80/CD81/CD82/CD87/CD89

- All Versions

Due to continued product enhancements, product image may differ slightly from actual product purchased.